



WALL Disney+



WALL Disney+

WALL Disney+

WALL Disney+





P01 / DY3001




P02 / DY3002



P03 / DY3003



P04 / DY3004



P05 / DY3005



P06 / DY3006



P07 / DY3007



P08 / DY3008



P09 / DY3009



P10 / DY3010



P11 / DY3011



P12 / DY3012



P13 / DY3013



P14 / DY3014



P15 / DY3015



P16 / DY3016



P17 / DY3017



P18 / DY3018



P19 / DY3019



P20 / DY3020



P21 / DY3021



P22 / DY3022



P23 / DY3023



P24 / DY3024



P25 / DY3025



P26 / DY3026



P27 / DY3027



P28 / DY3028



P29 / DY3029



P30 / DY3030



P31 / DY3031



P32 / DY3032




P33 / DY3033



P34 / DY3034



P35 / DY3035



P36 / DY3036



P37 / DY3037



P38 / DY3038



P39 / DY3039



P40 / DY3040



P41 / DY3041



P42 / DY3042



P43 / DY3043



P44 / DY3044




P45 / DY3045



P46 / DY3046



P47 / DY3047



P48 / DY3048



P49 / DY3049



P50 / DY3050



P51 / DY3051



P52 / DY3052



P53 / DY3053



P54 / DY3054



P55 / DY3055



P56 / DY3056




P57 / DY3057






Pattern:DY3001




Pattern:DY3002





Pattern:DY3003










Pattern:DY3004



Pattern:DY3005







Pattern:DY3006



Pattern:DY3007



















Pattern:DY3009





Pattern:DY3011








Pattern:DY3013



Pattern:DY3014




Pattern:DY3015













Pattern:DY3017



Pattern:DY3018




Pattern:DY3019




Pattern:DY3020











Pattern:DY3021







Pattern:DY3022







Pattern:DY3023




Pattern:DY3024





Pattern:DY3025



Pattern:DY3026



Pattern:DY3027




Pattern:DY3028







Pattern:DY3029



Pattern:DY3030






Pattern:DY3031



Pattern:DY3032




Pattern:DY3033






Pattern:DY3034









Pattern:DY3035






Pattern:DY3037



Pattern:DY3038






Pattern:DY3039






Pattern:DY3040












Pattern:DY3041






Pattern:DY3042




Pattern:DY3043





Pattern:DY3044



Pattern:DY3045



Pattern:DY3046




Pattern:DY3047



Pattern:DY3048





Pattern:DY30049



Pattern:DY3050




Pattern:DY3051









Pattern:DY3052





















Pattern:DY3057


Page Number	Pattern Number	Page Number	Pattern Number	Page Number	Pattern Number
01	DY3001	21	DY3021	41	DY3041
02	DY3002	22	DY3022	42	DY3042
03	DY3003	23	DY3023	43	DY3043
04	DY3004	24	DY3024	44	DY3044
05	DY3005	25	DY3025	45	DY3045
06	DY3006	26	DY3026	46	DY3046
07	DY3007	27	DY3027	47	DY3047
08	DY3008	28	DY3028	48	DY3048
09	DY3009	29	DY3029	49	DY3049
10	DY3010	30	DY3030	50	DY3050
11	DY3011	31	DY3031	51	DY3051
12	DY3012	32	DY3032	52	DY3052
13	DY3013	33	DY3033	53	DY3053
14	DY3014	34	DY3034	54	DY3054
15	DY3015	35	DY3035	55	DY3055
16	DY3016	36	DY3036	56	DY3056
17	DY3017	37	DY3037	57	DY3057
18	DY3018	38	DY3038		
19	DY3019	39	DY3039		
20	DY3020	40	DY3040		




•Lijn met roller op de wand aanbrengen
 •Encoller la mur à l'aide d'un rouleau
 •Apply paste with roller to the wall
 •Die Wand mit einem Roller einkleistern
 •Aplicar la cola directamente en la pared con un rodillo



•SMART paper op maat afknippen, klaar
 •Couper selon mesure
 •Cut SMART paper to size
 •SMART paper nach Maß schneiden
 •Aplicar el papel SMART (no tejido) directamente en la pared



•SMART paper direct op de wand aanbrengen
 •Poser le SMART paper sur le mur
 •Apply SMART paper directly to the wall
 •SMART paper direkt auf die Wand anbringen
 •Colar el papel SMART a la medida



•Zelfs jaren later eenvoudig droog te verwijderen
 •Facile à enlever, même après plusieurs années
 •Simple to remove even years later
 •Einfach trocken zu entfernen, auch nach mehreren Jahren
 •Fácil de sacar incluso después de mucho tiempo